

**Figure 1**  
**Vertical stepping**

a. A releases during each pulse.



During first pulse C and VERT operate, shaft rises to level 1, VON operates, E is energized.

B is slow release and stays operated when de-energized during each pulse.

b. E operates and holds

Further intermediate details of vertical stepping not shown.

(Continued on next sheet)



Key to symbols and relay index on last sheet


Path development for trunk hunting, digit absorption, and level blocking.

Step-by-step system			
ED-55242-32 G11 switch			
Auxiliary intertoll selector (D/A)			
num SXS-SK1052	iss 02	date 2020.01.27	sht 01
proj SXS study	type CDR	dwn DAK	of 01
laboratories dak			
scientific and technical undertakings			
Alamogordo, New Mexico			

**Figure 1**  
**Vertical stepping**

c. End of last pulse:  
VERT releases,  
C is de-energized  
but does not  
release  
immediately.


B now energized steadily.



Key to symbols and  
relay index on last sheet

d. C releases,  
path closed to  
spring 10 of D.

Go to, depending  
on normal post  
springs (NPS) operated:  
None: Fig 2  
LF: Fig. 3  
RF: Fig 4  
LR: Fig 5.




Path development for  
trunk hunting,  
digit absorption, and  
level blocking.

Step-by-step system			
ED-55242-32 G11 switch			
Auxiliary intertoll selector (D/A)			
num SXS-SK1052	iss 02	date 2020.01.27	sht 02
proj SXS study	type CDR	dwn DAK	of 01
laboratories dak scientific and technical undertakings Alamogordo, New Mexico			

**Figure 2**  
**No NPS contact**  
**operated ("normal"**  
**level).**


We arrive here  
 from Fig. 1d

a. C released  
 completes path  
 to operate ROT.



Key to symbols and  
 relay index on last sheet

b. Shaft rotates to step 1.  
 Rot. Int. opens,  
 releasing E, which  
 releases ROT.  
 We assume the  
 trunk at step 1  
 is busy, with  
 sleeve grounded.  
 That provides a potential  
 path seen in magenta.



Path development for  
 trunk hunting,  
 digit absorption, and  
 level blocking.

(Continued on  
 next sheet)


Step-by-step system			
ED-55242-32 G11 switch			
Auxiliary intertoll selector (D/A)			
num SXS-SK1052	iss 02	date 2020.01.27	sht 03
proj SXS study	type CDR	dwn DAK	of 01
laboratories dak			
scientific and technical undertakings			
Alamogordo, New Mexico			

**Figure 2**  
**No NPS contact**  
**operated ("normal"**  
**level).**

c. Rot. Int. closes,  
 E is energized from S


There is also a path  
 from E through F to ground  
 (shown here in magenta),  
 but the path from S "shorts  
 F out".

Key to symbols and  
 relay index on last sheet



d. E operates and  
 locks to ground.  
 E closes the path  
 to energize ROT.

(Continued on  
 next sheet)




Path development for  
 trunk hunting,  
 digit absorption, and  
 level blocking.

Step-by-step system			
ED-55242-32 G11 switch			
Auxiliary intertoll selector (D/A)			
num SXS-SK1052	iss 02	date 2020.01.27	sht 04
proj SXS study	type CDR	dwn DAK	of 01
laboratories dak scientific and technical undertakings Alamogordo, New Mexico			

**Figure 2**  
**No NPS contact**  
**operated ("normal"**  
**level).**


e. ROT operates,  
stepping the switch  
to step 2.  
Rot. Int. opens,  
de-energizing E and ROT.

We assume the trunk there  
is idle (no ground on S).



Key to symbols and  
relay index on last sheet

f. E and ROT release;  
Rot. Int. closes




(Continued on  
next sheet)

Path development for  
trunk hunting,  
digit absorption, and  
level blocking.

Step-by-step system			
ED-55242-32 G11 switch			
Auxiliary intertoll selector (D/A)			
num SXS-SK1052	iss 02	date 2020.01.27	sht 05
proj SXS study	type CDR	dwn DAK	of 01
laboratories dak			
scientific and technical undertakings			
Alamogordo, New Mexico			


**Figure 2**  
**No NPS contact**  
**operated ("normal"**  
**level).**

g. A path from ground through F and E energizes F and E, but the current is not enough to operate E.



Key to symbols and relay index on last sheet

h. F operates and cuts the connection through to the next stage. F also ties the sleeve from the next stage to the incoming sleeve. The distant switch sends ground back on the outgoing sleeve.



Path development for trunk hunting, digit absorption, and level blocking.

(Continued on next sheet)


Step-by-step system			
ED-55242-32 G11 switch			
Auxiliary intertoll selector (D/A)			
num SXS-SK1052	iss 02	date 2020.01.27	sht 06
proj SXS study	type CDR	dwn DAK	of 01
laboratories dak scientific and technical undertakings Alamogordo, New Mexico			



**Figure 3**  
**NPS LF contact**  
**operated ("absorb,**  
**do not unlock" level),**  
**not currently unlocked.**

We arrive here  
 from Fig. 1d


a. C released  
 completes path  
 to operate RLS..



Key to symbols and  
 relay index on last sheet

b. Shaft returns to  
 home position.  
 VON opens,  
 releasing RLS.

Go to Fig. 1A.




Path development for  
 trunk hunting,  
 digit absorption, and  
 level blocking.

Step-by-step system			
ED-55242-32 G11 switch			
Auxiliary intertoll selector (D/A)			
num SXS-SK1052	iss 02	date 2020.01.27	sht 08
proj SXS study	type CDR	dwn DAK	of 01
laboratories dak			
scientific and technical undertakings			
Alamogordo, New Mexico			

**Figure 4**  
**NPS RF contact**  
**operated ("absorb,**  
**unlock" level),**  
**not currently unlocked.**


We arrive here  
 from Fig. 1d

a. C released  
 completes path  
 to D winding T-B.  
 D is energized for  
 1st step operation.



Key to symbols and  
 relay index on last sheet

b. D operates to  
 1st step. That closes  
 path to energize RLS.  
 D closes path through  
 its own LM-RM  
 winding, but that is  
 shorted out for now.



Path development for  
 trunk hunting,  
 digit absorption, and  
 level blocking.

Step-by-step system			
ED-55242-32 G11 switch			
Auxiliary intertoll selector (D/A)			
num SXS-SK1052	iss 02	date 2020.01.27	sht 09
proj SXS study	type CDR	dwn DAK	of 01
laboratories dak			
scientific and technical undertakings			
Alamogordo, New Mexico			



**Figure 4**  
**NPS RF contact**  
**operated ("absorb,**  
**unlock" level),**  
**not currently unlocked.**

c. RLS operates  
 and locks to  
 ground. RLS  
 releases switch shaft.  
 RLS 1-2 opens original  
 operate path to D.

The path through  
 both windings of D  
 operates D fully.  
 That establishes the  
 "unlocked" mode.  
 (See Fig. 6.)

d. When shaft is  
 home, VON 3-4 opens,  
 releasing RLS.

Then go to Fig. 1A.




Key to symbols and  
 relay index on last sheet

Path development for  
 trunk hunting,  
 digit absorption, and  
 level blocking.

Step-by-step system			
ED-55242-32 G11 switch			
Auxiliary intertoll selector (D/A)			
num SXS-SK1052	iss 02	date 2020.01.27	sht 10
proj SXS study	type CDR	dwn DAK	of 01
laboratories dak			
scientific and technical undertakings			
Alamogordo, New Mexico			

**Figure 5**  
**NPS LR contact**  
**operated (level blocked),**  
**not currently**  
**unlocked.**




a. C released  
 completes path  
 to operate ROT.

Path through NPS LR 2-3  
 "fakes" busy condition  
 on all trunks. Trunk  
 hunting proceeds as seen  
 on Figs. 2c-d.

b. When shaft turns  
 to rotary step 11,  
 11RS 1-2 opens, halting  
 the stepping process.

Other 11RS contacts  
 (not seen) send  
 reorder tone to  
 the calling line.



Path development for  
 trunk hunting,  
 digit absorption, and  
 level blocking.

Step-by-step system			
ED-55242-32 G11 switch			
Auxiliary intertoll selector (D/A)			
num SXS-SK1052	iss 02	date 2020.01.27	sht
proj SXS study	type CDR	dwn DAK	of 01
laboratories dak			
scientific and technical undertakings			
Alamogordo, New Mexico			

## Figure 6 Consequences of "locked" status



"Locked" status of the digit absorption and level blocking system is brought about when the D relay is operated. In that case, neither type of digit absorption nor level blocking will happen on levels set for those.

- Absorb and do not unlock: See Fig. 3a. With D operated, contact D9-10-11 in effect rearranges the circuit to as seen in Fig. 2a, and operation proceeds as for a "normal" level; the digit is not absorbed.
- Absorb and unlock: see Fig. 4a. With D operated, contact D9-10-11 in effect rearranges the circuit to as seen in Fig. 2a, and operation proceeds as for a "normal" level; the digit is not absorbed.
- Level blocked: See Fig. 5a. With D operated, contact D7-8 opens the path that "fakes" trunk busy at all rotary steps, so operation proceeds as for a "normal" level; the level is not blocked.

Path development for  
trunk hunting,  
digit absorption, and  
level blocking.

Step-by-step system ED-55242-32 G11 switch Auxiliary intertoll selector (D/A)			
num	SXS-SK1052	iss	02
date	2020.01.27	sht	12
proj	SXS study	type	CDR
dwn	DAK	of	01
<b>laboratories dak</b> scientific and technical undertakings Alamogordo, New Mexico			

# Key

-  Relay released
-  Coil energized but relay not yet operated
-  Relay operated
-  Coil energized but current too little to operate (marginal relay)
-  Coil energized for 1st step operation
-  Relay operated to 1st step
-  Relay de-energized but not yet released
-  Just now or recently released
-  Status varies

-  Path newly shown this figure
-  Path first shown earlier
-  Contact change significant

## Relays with functions\*

- A Line
- B Line slow release
- C Vertical stepping in process
- D Level unlock memory
- E Rotary step
- F Cut through

\*Only relays seen in this drawing.

Path development for trunk hunting, digit absorption, and level blocking.

Step-by-step system ED-55242-32 G11 switch Auxiliary intertoll selector (D/A)			
<small>num</small> SXS-SK1052	<small>iss</small> 02	<small>date</small> 2020.01.27	<small>sht</small> 13
<small>proj</small> SXS study	<small>type</small> CDR	<small>dwn</small> DAK	<small>of</small> 01
<b>laboratories dak</b> scientific and technical undertakings Alamogordo, New Mexico			