

APRIL 30, 1979

No. 252 TYPE RELAYS

(Card No. 2)

SEE RATINGS
BELOW

For general information and illustration, see Card No. 1.

| Code No. | Windings | (†) Rated Resistance (Ohms) | (†) Operate (Ampere) | (†) Non-Operate (Ampere) | (†) Release (Ampere) | Horizontal M't'g Centers (Inches) | Rating |
|----------|---|-----------------------------|-------------------------|--------------------------|-----------------------------|-----------------------------------|---------------------|
| (h)252A | { Front Rear | (a) 375 1400 | (b)(k).0133 — | (b)(f).0103 — | (c).0133 } — } | 2-1/8 | A.T.&T.Co.Std. |
| 252B | { Front Pri. Front Sec. (N.I.) Pri. & Sec. in Multiple Rear | 850 300 222 950 | — — (b).0505 — | — — (d)(e) — | — — (c).0555 } — } | 2-3/8 | A.T.&T.Co.Std. (ML) |

(†) See Card No. 1.

(a) Plus or minus 10%.

(b) With current in same direction.

(c) With current in opposite direction.

(d) Contact 1 will not make on .038 ampere with current in same direction.

(e) Contact 1 will not make on .190 ampere with current in opposite direction.

(f) Will not operate on .0675 ampere with current in opposite direction.

(h) Contacts 1 and 3 have No. 2 metal contacts.

(k) Holds on .0100 ampere with current in opposite direction.